



**EXPLODED VIEW-1**

Parts marked with \* require longer delivery time.

REF. NO.	PARTS NO.	DESCRIPTION	REMARKS
1 - 1	*5800307000	Screw, Head Housing	
1 - 2	*5800306900	Screw, Top Panel	
1 - 3	*5800307300	Housing Assy, Head; (2)	
1 - 4	*5800297500	Cap, Tension Roller	
1 - 5	5800297800	Roller Assy, Tension	
1 - 6	*5800312100	Cap, Pinch Roller	
1 - 7	*6011266000	Collar, Bearing	
1 - 8	5800291500	Pinch Roller (1/2")	
1 - 9	5800288000	Knob, Pitch Control, (PH)	
1 - 10	*5800288600	Cap, Dust	
1 - 11	*5800293000	Panel, Transport	
1 - 12	*5800286900	Panel Assy, Ampl; (A)	
1 - 13	*5800286800	Panel Assy, Top, Dress; (8)	
1 - 14	5800173100	Button, Power Switch	
1 - 15	5800288200	Button, Switch	
1 - 16	5800288100	Knob, Cue	
1 - 17	5800288300	Button, Push	
1 - 18	*5800301200	Shield Assy, Front	
1 - 19	*5800294400	Bonnet	
1 - 20	*5800347900	Case, Rear; (8)	
1 - 21	*5800307100	Collar, Foot; (A)	
1 - 22	*5800348300	Bottom Assy; (B)	
1 - 23	*5800288500	Foot	
1 - 24	*5800067700	Nut, Lock	
1 - 25	*5800289500	Cushion, Bonnet	
1 - 26	*5800287400	Escutcheon; BL	

(Continued from page 92)

REF. NO.	PART NO.	DESCRIPTION	REMARKS
3 - 56	*5534850000	Cushion, Stopper	
3 - 57	*5534849000	Flywheel	
3 - 58	5534468000	Belt, Capstan	
3 - 59	*5800300300	Chassis Assy, Main	
3 - 60	*5534850000	Cushion, Stopper	
3 - 61	*5800298200	Shaft, Guide Roller	
3 - 62	5800298100	Roller Sub Assy, Guide	
3 - 63	*5800312200	Cap, Guide Roller	
3 - 64	*5800297700	Shaft, Tension Arm; (L)	
3 - 65	*5800297600	Collar, Tension Arm	
3 - 66	*5800304000	Screw, Lock	
3 - 67	*5122172000	Connector Socket, 10P	
3 - 68	*5122170000	Connector, Socket, 8P	
3 - 69	5312000100	Counter, FL4028	
3 - 70	*5200074000	PCB Assy, Counter	
3 - 71	*5800294900	Base Assy, Counter	
3 - 72	*5581038000	Clamper, Cord	
3 - 73	*5555570000	Cushion, B	
3 - 74	*5800307200	Bolt, Cap. M3 x 6	
3 - 75	*5800326600	Spacer, Reel	
3 - 76	*5785150400	Washer, Wave; (W-W-4)	
3 - 77	*5800348700	Screw, Head Hold	
3 - 78	*5781733010	Bolt, Cap, M3 x 10	